

# TUYA Fingerprint Lock V2.1

## 1.Specifications:

### 1.1 Technical parameters:

Item	Value	Item	Value
<b>Operating power</b>	4pcs dry batteries	<b>Capacity</b>	Finger 50, Card or Passcode 249
<b>Operating current</b>	< 135mA	<b>Emergency</b>	Usb 5v
<b>Operating temperature</b>	-10℃—60℃	<b>Card type</b>	Mifare

### 1.2 Factory Default:

Item	Value
<b>Default Menu</b>	Press "0 #" to enter Menu, Enter default admin passcode "123456" and "#"
	Press button on the back 5 Seconds, hear "du du du", then stop pressing, it can exchange mode "Normal Open" and "Auto Lock"
	Press button on the back 15 Seconds, hear "du", then stop pressing, wait about 10 Seconds, hear "Factory restoration succeeded"

### 1.3 Tuya app steps


1. Download and install TUYA app from the app store
2. Follow the prompts to register or log in:
3. Add device:

After logging in, click the [Add device] button, or click the plus sign in the upper right corner to add;

On the Add Device page, select Add Device (you need to allow location permission and Bluetooth);

And broadcast "Please pair administrator", input the fingerprint or password of the administrator (the initial unregistered password is "123456 #") to pair;

After successful pairing, perform APP operation as required;



### Installation Video :

<https://m.v.qq.com/z/msite/play-short/index.html?vid=b335981ahi9>



## 2. Programming Guide

Press “0” “#” to enter the menu, Enter Administrator Authentication, default admin passcode “123456” and “#”, then as follow :

Remark: “\*” to return, “#”to confirm.

Remark: All password can be 6~10digits.

Press “1” Administrator Setting	Press “1” Add Administrator	
	Press “2” Delete Administrator	
Press “2” Common Users Setting	Press “1” Add Common Users	
	Press “2” Delete Common Users	
	Press “3” Add Remote Control	
	Press “4” Delete Remote Control	
Press “3” SystemSetting	Press “1” Time Setting	
	Press “2”Function Setting	Press “1” Language Setting (1 Chinese; 2 English)
		Press “2” Anti demolition setting (Open or Close)
		Press “3” Normally open mode (Open or Close)
		Press “4” Return to factory (# to confirm)
	Press “3” Volume Adjustment	Press “1” increase Volume
		Press “2” decrease Volume
		Press “3” Enable Mute Mode
	Press “4” One Key Unlock (Open or Close)	
	Press “4” Others Setting	Press “1” Event record
Press “2” Administrator statistics		
Press “3” General user statistics		
Press “4” Version information		